



FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



INSTALLATION DETAILS

Disclaimer: These details are general design details for use as a guide. Any use is at their own discretion and risk.


FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.01 - TYPICAL FIXING DETAIL
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.


FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.02 - INTERMEDIATE DETAIL
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.


FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.03 - HORIZONTAL CLOSED JOINT
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel FX-06-VSF Visible Screw Fix




D.04 - BASE DETAIL

SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel FX-06-VSF Visible Screw Fix




D.05 - EXTERNAL CORNER

SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix




D.06 - INTERNAL CORNER
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel

FX-06-VSF Visible Screw Fix




D.07 - WALL ABUTMENT

SCALE 1:2

Disclaimer: These details are general design details for use as a guide. Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.08 - HORIZONTAL CONTROL JOINT
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FX-06-VSF Visible Screw Fix



D.09 - WINDOW HEAD


SCALE 1:2

Disclaimer: These details are general design details for use as a guide. Any use is at their own discretion and risk.



FUNDERMAX High Pressure Laminate Panel

FX-06-VSF Visible Screw Fix




D.10 - WINDOW JAMB

SCALE 1:2

Disclaimer: These details are general design details for use as a guide. Any use is at their own discretion and risk.


FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.11 - WINDOW SILL
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix




D.12 - HEAD AT SLAB JUNCTION

SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel

FX-06-VSF Visible Screw Fix




D.13 - SOFFIT JUNCTION

SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.

FUNDERMAX High Pressure Laminate Panel
FX-06-VSF Visible Screw Fix



D.14 - PARAPET DETAIL
SCALE 1:2

Disclaimer: These details are general design details for use as a guide.
Any use is at their own discretion and risk.